


**MSK1100** Magnetsensor

**MB100/1** Magnetband



## DEUTSCH




Sensordarstellungen sind exemplarisch und gültig für alle Bauformen, sofern nicht gesondert beschrieben.

### 1. Gewährleistungshinweise

- Lesen Sie vor der Montage und der Inbetriebnahme dieses Dokument sorgfältig durch. Beachten Sie zu Ihrer eigenen Sicherheit und der Betriebssicherheit alle Warnungen und Hinweise.
- Ihr Produkt hat unser Werk in geprüfem und betriebsbereitem Zustand verlassen. Für den Betrieb gelten die angegebenen Spezifikationen und die Angaben auf dem Typenschild als Bedingung.
- Garantieansprüche gelten nur für Produkte der Firma SIKO GmbH. Bei dem Einsatz in Verbindung mit Fremdprodukten besteht für das Gesamtsystem kein Garantieanspruch.
- Reparaturen dürfen nur im Werk vorgenommen werden. Für weitere Fragen steht Ihnen die Firma SIKO GmbH gerne zur Verfügung.

### 2. Identifikation

**Magnetband:** Das Magnetband ist durch eine fortlaufende Bedruckung identifizierbar.



**Magnetsensor:** Das Typenschild zeigt den Gerätetyp mit Variantenummer. Die Lieferpapiere ordnen

jeder Variantenummer eine detaillierte Bestellbezeichnung zu.

z. B. MSK1100-0023  
 ————— Varianten-Nr.  
 ————— Geräte-Typ

### 3. Mechanische Montage

Die Montage darf nur gemäß der angegebenen IP-Schutzart vorgenommen werden. Das System muss ggfs. zusätzlich gegen schädliche Umwelteinflüsse, wie z. B. Spritzwasser, Lösungsmittel, Staub, Schläge, Vibrationen, starke Temperaturschwankungen geschützt werden.

#### 3.1 Montage Magnetband

Die Montage muss plan zur Montagefläche bzw. der zu messenden Strecke erfolgen. Welligkeiten verschlechtern immer die Messgenauigkeit.

Aus technischen Gründen muss bei der Länge, gegenüber der Messstrecke, ein Zumaß von min. 60 mm berücksichtigt werden.

**Achtung!** Um **optimale Verklebungen** zu erreichen müssen alle antiadhäsiven Fremdstoffen (Öl, Fett, Staub usw.) durch möglichst rückstandslos verdunstende Reinigungsmittel entfernt werden. Als Reinigungsmittel eignen sich u. a. Ketone (Aceton) oder Alkohole, die u. a. von den Firmen Loctite und 3M als Schnellreiniger angeboten werden. Die Klebeflächen müssen trocken sein und es ist mit höchstmöglichem Anpreßdruck zu verkleben. Die Verklebungstemperatur ist optimal zwischen 20 °C und 30 °C in trockenen Räumen.

**Tip!** Bei Verklebung langer Bänder sollte die Schutzfolie des Klebebandes über eine kurze Teilstrecke abgezogen werden, um das Band zu fixieren. Daraufhin erfolgt das Ausrichten des Bandes. Nun kann über die restliche Länge die Schutzfolie, unter gleichzeitigem Andruck des Bandes, seitlich herausgezogen werden (als Hilfsmittel kann eine Tapetenandrückwalze verwendet werden).

#### Montageschritte (Abb. 1)

- Befestigungsfläche (1) sorgfältig reinigen.
- Am Magnetband die Schutzfolie (2) des Klebebandes (3) entfernen.
- Magnetband (4) aufkleben.
- Magnetbandoberfläche sorgfältig reinigen.
- Am Abdeckband (5) die Schutzfolie (6) des Klebebandes entfernen.
- Abdeckband aufkleben (an beiden Enden leicht überlappen lassen).

- Die überlappenden Enden des Abdeckbandes gegen Ablösen sichern.




Abb. 1: Montage Magnetband



**Achtung!** Die Beeinflussung durch magnetische Felder ist zu vermeiden. Insbesondere dürfen keine Magnetfelder (z. B. Haftmagnete oder andere Dauermagnete) in direkten Kontakt mit dem Magnetband geraten. In stromlosem Zustand werden Bewegungen oder Verstellungen des Magnetsensors von der Folgeelektronik nicht erkannt und erfasst.

### Montagebeispiele

Die einfache Montageart, durch angeschrägtes Schutzband (Abb. 2), ist nur in sehr geschützter Umgebung zu empfehlen. Bei ungeschützter Umgebung besteht Abschälgefahr. In solchen Fällen sind Montagearten, wie in Abb. 3 und 4 gezeigt, geeigneter.

Den optimalen Schutz bietet die Montage in einer Nut (Abb. 5), die so tief sein sollte, dass das Magnetband vollständig darin eingebettet werden kann.




Abb. 2

Abb. 3




Abb. 4

Abb. 5

### 3.2 Montage Magnetsensor MSK1100

Der Magnetsensor MSK1100 kann durch Verwendung von 2 Schrauben M3 über die Langlöcher befestigt werden. Es wird empfohlen die Beiliegenden Befestigungsschrauben zu verwenden (Anzugsmoment 1 Nm).

- Kabel sind so zu verlegen, dass keine Beschädigungsgefahr besteht. Zugentlastung und wenn nötig Schleppkette oder Schutzschlauch vorsehen.
- Aufrichtige Ausrichtung bezüglich der Zählrichtung achten (Abb. 6). Dies ist unerheblich falls sich die

Zählrichtung in der elektronischen Auswertung umkehren läßt (wie z. B. bei den Magnetbandanzeigen von SIKO).

- Abstandslehre vollflächig zwischen Sensor und Magnetband legen.

**Achtung!** Die Toleranz- und Abstandsmaße müssen über die gesamte Messstrecke eingehalten werden. Der maximale Abstand ohne Abdeckband beträgt 0.4 mm. Bei Verwendung eines Abdeckbandes reduziert sich der eff. Abstand um die Dicke des Abdeckbandes inkl. Klebefolie. Der Sensor darf das Magnetband nicht berühren.



### Anwendung LINEAR MSK1100 mit MB100/1:




Abb. 6: Definition der Zählrichtung mit Magnetband und Montage Sensor/Magnetband, Abstandsmaße, Toleranzen

### Anwendung mit Endschaltermagnet:




Abb. 7: Endschaltermagnet

## 4. Elektrischer Anschluss

- Verdrahtungsarbeiten dürfen nur spannungslos erfolgen!
- Vor dem Einschalten sind alle Leitungsanschlüsse und Steckverbindungen zu überprüfen.

### Hinweise zur Störsicherheit

Alle Anschlüsse sind gegen äußere Störeinflüsse geschützt. **Der Einsatzort ist aber so zu wählen, dass induktive oder kapazitive Störungen nicht auf den Sensor oder dessen Anschlussleitung einwirken können!** Durch geeignete Kabelführung und Verdrahtung können Störeinflüsse (z. B. von Schaltnetzteilen, Motoren, getakteten Reglern oder Schützen) vermindert werden.

### Erforderliche Maßnahmen:

- Nur geschirmtes Kabel verwenden. Den Kabelschirm beidseitig auflegen. Litzenquerschnitt der Leitungen min. 0.14 mm<sup>2</sup>; max. 0.5 mm<sup>2</sup>.
- Die Verdrahtung von Abschirmung und Masse (0 V) muss sternförmig und großflächig erfolgen. Der Anschluss der Abschirmung an den Potentialausgleich muss großflächig (niederimpedant) erfolgen.
- Das System muss in möglichst großem Abstand von Leitungen eingebaut werden, die mit Störungen belastet sind; ggfs. sind **zusätzliche Maßnahmen wie Schirmbleche oder metallisierte Gehäuse** vorzusehen. Leitungsführungen parallel zu Energieleitungen vermeiden.
- Schutzspulen müssen mit Funkenlöschgliedern beschaltet sein.

### Spannungsversorgung


Die Spannungswerte sind abhängig von der Sensorausführung und sind den Lieferpapieren sowie dem Typenschild zu entnehmen.

z. B.: 6.5 ... 30 V DC



**Achtung!** Die maximale Länge des Anschlusskabels zwischen Sensor und Nachfolgeelektronik beachten.

## 4.1 Anschlusshinweis nach RS422 Norm



### Endschalter:

Bei der Beschaltung ist die max. Spannung und der max. zugelassene Strom zu beachten:

$U_{max} = 50 \text{ V}$

$I_{max} = 50 \text{ mA}$



Die Endschalter sind als Open-Collector-Ausgang (OC) ausgeführt und dienen dazu, einen Anschluss an ein höheres Spannungsniveau zu erlauben. Ohne weitere Beschaltung des Ausgangs, kann z. B. ein Relais an den Ausgang geschaltet werden. Um den OC-Ausgang des Sensors zu schützen ist es zwingend erforderlich, das Relais mit einem Löschglied (z. B. Freilaufdiode) zu beschalten. Alternativ wäre auch eine Optoentkopplung möglich.




Abb. 8: Open Collector mit Relais

Werden die Ausgänge nicht benötigt, müssen diese wahlweise mit einem Pull Up Widerstand beschaltet oder auf Masse gelegt werden.




Abb. 9: Open Collector mit Pull Up Widerstand bzw. Masseschaltung

## 4.2 Anschlussarten

**E1:** Anschluss mit offenen Kabelenden.



**Achtung!** Verzinnete Litzen dürfen nicht in Verbindung mit Schraubklemmverbindungen eingesetzt werden.

invertiert ohne Indexsignal	invertiert mit Indexsignal	Signal
blau	grau	L1
violett	weiß	L2
---	violett	/I
---	blau	I
grün	grün	/B
orange	orange	B
rot	rot	A
gelb	gelb	/A
schwarz	schwarz	GND
braun	braun	+UB

1. Ummantelung entfernen.
2. Schirm auftrennen und verdrehen.
3. Litzen ca. 5 mm absolieren und verdrehen.
4. Aderendhülsen aufquetschen.




Abb. 10: Anschluss E1

**E8:** Anschluss mit 15-poligem D-SUB Stecker

invertiert ohne Indexsignal	invertiert mit Indexsignal	Signal
Pin 1	Pin 1	L1
2	2	L2
---	3	/I
---	4	I
5	5	/B
6	6	B
7	7	A
8	8	/A
10	10	GND
12	12	+UB
14	14	Schirm
3, 4, 9, 11, 13, 15	9, 11, 13, 15	---





Abb. 11: Anschlussart E8

## 5. Inbetriebnahme

Nach ordnungsgemäßer Montage und Verdrahtung kann das Messsystem durch Einschalten der Versorgungsspannung in Betrieb genommen werden. Das Gerät initialisiert sich selbstständig nach dem Einschalten. Die "Power"-Leuchtdiode (grün) im Sensorgehäuse leuchtet. Beim Verfahren des Magnetsensors über das Magnetband blinken die Leuchtdioden A, B und I (rot) entsprechend auf. L1 oder L2 leuchten solange der entsprechende Endschaltermagnet betätigt wird (siehe Abb. 7).



Das Messsystem MSK1100+MB100/1 ist Bestandteil eines inkrementalen Messsystem, dass zur absoluten Messung an einer definierten Stelle (Referenzpunkt) referenziert werden muss. Dazu muss das Referenzsignal mit dem Signal eines Referenzwertgebers (z.B. Näherungsschalter) verknüpft werden.

## 6. Verfahrensgeschwindigkeiten (m/s)

Formel zur Berechnung der Verfahrensgeschwindigkeit:

$$V_{\text{max.}} = \frac{\text{Auflösung in } \mu\text{m}}{\text{Pulsabstand in } \mu\text{s}} \times 0.8$$

(in m/s)

Beispiel:

Auflösung: 1  $\mu\text{m}$   
Pulsabstand: 0.25  $\mu\text{s}$

$$V = \frac{1}{0.25} \times 0.8 = 3.2 \text{ m/s}$$

Verfahrensgeschwindigkeit in m/s	Auflösung in $\mu\text{m}$				Pulsabstand ( $\mu\text{s}$ )	Zählfrequenz (kHz)
	0.2	1	2	5		
0.64	3.20	6.40	16.00	0.25	1000.00	
0.32	1.60	3.20	8.00	0.50	500.00	
0.16	0.80	1.60	4.00	1.00	250.00	
0.08	0.40	0.80	2.00	2.0	125.00	

## 7. Ausgangssignale


Die Auswertelektronik setzt die magnetischen Längeninformationen des Magnetsensors in inkrementale Ausgangssignale um. Die Ausgabe der Signale erfolgt geschwindigkeitsproportional.

**Es ist zu beachten, dass im Stillstand Impulse von der Breite des eingestellten Pulsabstandes auftreten können** (bedingt durch das interne Interpolationsverfahren).



**Achtung!** Bei der Dimensionierung der Nachfolgeelektronik ist zu beachten, dass diese für den eingestellten Pulsabstand bzw. Zählfrequenz ausgelegt ist.


### Signalfolge



**Hinweis:** Die Lage des Indexsignals I zu den Signalen A und B ist nicht definiert und kann von der Zeichnung abweichen.



**Hinweis:** Bei Indexsignalbreite von 4 Inkrementen (= 360°), ist der Index erst nach dem 5. Zähler Schritt (Inkrement) auswertbar. Nach dem Einschalten der Betriebsspannung entsprechende Verzögerung berücksichtigen.



## 8. Wartung

Die Oberfläche des Magnetbandes ist bei starker Verschmutzung durch Staub, Späne, Feuchtigkeit usw., von Zeit zu Zeit mit einem weichen Lappen zu reinigen.

## 9. Fehlerbehandlung


Typische Fehler, die bei Anbau und Betrieb auftreten:

- Das Magnetband wurde falsch montiert / aktive Seite nach unten (siehe Kapitel 3.1).
- Zum Schutz des Magnetbandes wurde nicht das mitgelieferte Abdeckband verwendet. Das Abdeckband muss nicht magnetisierbar sein.
- Der Sensor ist nicht, oder nicht korrekt angeschlossen (Pinbelegung Kapitel 4.2).
- Die Abstandstoleranz zwischen Sensor und Magnetband/Magnetring wurde nicht eingehalten (beim Band über die **gesamte** Messstrecke!) (Abb. 6).
- Kabelunterbrechung / Abtrennung durch scharfe Kanten / Quetschung.
- Der Sensor ist mit der aktiven Seite vom Band abgewandt montiert (Abb. 6).
- Der Sensor wurde nicht entsprechend Abb. 6 ausgerichtet.



# MSK1100 Magnetic sensor

# MB100/1 Magnetic strip



## ENGLISH




Exemplary sensor illustrations are valid for all sensor types unless described separately.

### 1. Warranty information

- In order to carry out installation correctly, we strongly recommend this document is read very carefully. This will ensure your own safety and the operating reliability of the device.
- Your device has been quality controlled, tested and is ready for use. Please observe all warnings and information which are marked either directly on the device or specified in this document.
- Warranty can only be claimed for components supplied by SIKO GmbH. If the system is used together with other products, there is no warranty for the complete system.
- Repairs should be carried out only at our works. If any information is missing or unclear, please contact the SIKO sales staff.


### 2. Identification

**Magnetic strip:** identification by printing on the strip.



**Magnetic sensor:** Please check the particular type of unit and type number from the identification plate. Type number and the corresponding version

are indicated in the delivery documentation.



### 3. Installation

For mounting, the degree of protection specified must be observed. If necessary, protect the unit against environmental influences such as sprayed water, dust, knocks, extreme temperatures.

#### 3.1 Mounting the magnetic strip

The mounting surface / measuring track must be flat. Buckles or bumps will lead to measuring inaccuracies.

For technical reasons the strip should be min. 60 mm longer than the actual measuring distance.

**Attention!** To guarantee optimal adhesion oil, grease dust etc. must be removed by using cleansing agents which evaporate without leaving residues. Suitable cleansing agents are e. g. ketones (acetone) or alcohols; Messrs. Loctite and 3M can both supply such cleansing liquid. Make sure that the surface to be glued is dry and apply the strip with maximum pressure. Glueing should preferably be undertaken at temperatures between 20 °C to 30 °C and in dry atmosphere.



**Advice!** When applying long pieces of magnetic strip do not immediately remove the complete protective foil, but rather peel back a short part from the end sufficient to fix the strip. Now align the strip. As the protective strip is then peeled back and out press the tape firmly onto the mounting surface. A wall paper roller wheel could be used to assist in applying pressure onto the magnetic strip when fixing it in position.

#### Mounting steps (Fig. 1)

- Clean mounting surface (1) carefully.
- Remove protective foil (2) from the adhesive side of the magnetic strip (3).
- Stick down the magnetic strip (4).
- Clean surface of magnetic strip carefully.
- Remove protective foil (6) from adhesive tape on the cover strip (5).
- Fix cover strip (both ends should slightly overlap).
- Also fix cover strip's ends to avoid unintentional peeling.




Fig. 1: Mounting of the magnetic strip



**Attention!** Do not expose the system to magnetic fields. Any direct contact of the magnetic strip with magnetic fields (e. g. adhesive magnets or other permanent magnets) is to be avoided. Sensor movements during power loss are not captured by the follower electronics.

### Mounting examples

Mounting with chamfered ends (fig. 2) is not recommended unless the strip is installed in a safe and protected place without environmental influences. In less protected mounting places the strip may peel. There we recommend mounting accord. to fig. 3 and 4.

Mounting in a groove (fig. 5) best protects the magnetic strip. The groove should be deep enough to totally embed the magnetic strip.




Fig. 2

Fig. 3




Fig. 4

Fig. 5

### 3.2 Mounting of the magnetic sensor MSK1100

The magnetic sensor MSK1100 can be fastened by using two bolts M3 over the elongated holes. We recommend to use the enclosed fixing screws (fastening torque 1 Nm).

- Cables should be layed in such a way that there is no danger of damaging. Provide ten-sion relief and drag chain or casing, if necessary.
- Observe the correct alignment with regard to the counting direction (fig. 6). This does not apply if the counting direction can be reversed in the electronic interpretation (e. g. in SIKO's magnetic-strip displays).
- Place distance gauge with its complete surface between sensor and magnetic tape.

**Attention!** The tolerance and gap measures must be observed over the whole measuring length. The max. gap without cover strip is 0.4 mm. When using cover strip, the gap is reduced by the thickness of cover strip including its adhesive tape. Sensor must not touch the magnetic strip.



### LINEAR application MSK1100 with MB100/1:




Fig. 6: Definition of the counting direction with magnetic strip and assemblage sensor/magnetic ring, gap measure, tolerances

### Application with limit switch magnet:




Fig. 7: Limit switch magnet

## 4. Electrical connection

- Wiring must only be carried out with power off!
- Check all lines and connections before switching on the equipment!



## Interference and distortion

All connections are protected against the effects of interference. **The location should be selected to ensure that no capacitive or inductive interferences can affect the sensor or the connection lines!** Suitable wiring layout and choice of cable can minimise the effects of interference (e. g. interference caused by SMPS, motors, cyclic controls and contactors).

### Necessary measures:

- Only screened cable should be used. Wire cross section is to be at least  $0.14 \text{ mm}^2$ , max.  $0.5 \text{ mm}^2$ .
- Wiring to the screen and ground (0 V) must be secured to a good point. Ensure that the connection of the screen and earth is made to a large surface area with a sound connection to minimise impedance.
- The system should be positioned well away from cables with interference; if necessary a **protective screen or metal housing** must be provided. The running of wiring parallel to the mains supply should be avoided.
- Contactor coils must be linked with spark suppression.

### Supply voltage


The voltages depend on the sensor designs; they are to be taken from the delivery documentation and the identification plate.

**e. g.:**      **6.5 ... 30 V DC**



**Attention!** When connecting sensor and follower electronics, please do not exceed the max. admissible cable length.

### 4.1 Connection note acc. to RS422 standard



## Limit Switch:

For wiring, follow the specifications for maximum voltage and maximum permissible current:

$U_{max} = 50 \text{ V}$

$I_{max} = 50 \text{ mA}$



The limit switches are designed as Open-Collector (OC) output and serve for enabling connection to a higher voltage level. For instance, a relay can be connected to the output without additional wiring of the output. In order to protect the sensor's OC output it is mandatory to wire the relay with a quenching circuit (e.g. free-wheeling diode). Alternatively, opto-decoupling would be possible.




Fig. 8: Open Collector with relay

If the outputs are not required, they must either be wired with a pull-up resistor or connected to ground.




Fig. 9: Open Collector with pull-up resistor or ground connection

### 4.2 Connection type

**E1:** Flying leads.

**Attention!** Tinned strands must not be used in combination with screw/clamp connections.



inverted without index signal	inverted with index signal	Signal
blue	grey	L1
violet	white	L2
---	violet	/I
---	blue	I
green	green	/B
orange	orange	B
red	red	A
yellow	yellow	/A
black	black	GND
brown	brown	+UB

1. Remove cable coating.
2. Open screening and twist it.
3. Strip stranded wires to a length of 5 mm and twist them.
4. Pinch stranded wires.




Fig. 10: Connection type E1

E8: Connection with 15-pole D-SUB plug.

inverted without index signal	inverted with index signal	Signal
Pin 1	Pin 1	L1
2	2	L2
---	3	/I
---	4	I
5	5	/B
6	6	B
7	7	A
8	8	/A
10	10	GND
12	12	+UB
14	14	screening
3,4,9,11,13,15	9, 11, 13, 15	---





Fig. 11: Connection type E8

## 5. Commissioning

Following proper installation and wiring, the measuring system can be commissioned by switching on the supply voltage. After switching on, the device initializes itself independently. The "power" LED (green) in the sensor housing lights up. While the magnetic sensor travels over the magnetic strip, the LEDs A, B, and I (red) are lighting accordingly. L1 or L2 are glowing as long as the respective limit switch magnet is actuated (see fig. 7).



The measuring system MSK1100+MB100/1 is a component of an incremental measuring system which must be referenced at a defined position (reference point) for absolute measurement. For this purpose, the reference signal must be linked to the signal of a reference value encoder (e. g., proximity switch).

## 6. Travel speeds (m/s)

Formula for calculating the travel speed:

Example:

$$V \text{ max. (in m/s)} = \frac{\text{Resolution in } \mu\text{m}}{\text{Pulse interval in } \mu\text{s}} \times 0.8$$

Resolution: 1  $\mu\text{m}$

Pulse interval: 0.25  $\mu\text{s}$

$$V = \frac{1}{0.25} \times 0.8 = 3.2 \text{ m/s}$$

Travel speed m/s	Resolution in $\mu\text{m}$				Pulse interval ( $\mu\text{s}$ )	Counting frequency (kHz)
	0.2	1	2	5		
0.64	3.20	6.40	16.00	0.25	1000.00	
0.32	1.60	3.20	8.00	0.50	500.00	
0.16	0.80	1.60	4.00	1.00	250.00	
0.08	0.40	0.80	2.00	2.00	125.00	


## 7. Output signals

The translation module translates the length information of the magnetic sensor into incremental output signals with real-time processing of the output signals.

**Please note that pulses having the width of the pulse interval set can occur at standstill of the device** (caused by the internal interpolation method).

**Caution!** When dimensioning the follow-on electronics please take care that it is adjusted to the set pulse interval or counting frequency, respectively.


## Signal sequence



**Note:** The position of the index signal I, respectively, with respect to signals A and B is not defined and can deviate from the drawing.



**Note:** With a 4-increment wide (= 360°) index signal, index signal interpretation can be made after the 5th counting step (increment) only. Corresponding time delay has to be considered when power is switched on.



## 8. Maintenance

We recommend cleaning the magnetic strip's surface from time to time with a soft rag. This avoids dirt (dust, chips, humidity ...) sticking to the strip.

## 9. Trouble shooting

Below are some typical errors which may occur during installation and operation:

- Magnetic strip incorrectly mounted (active surface must be mounted towards the sensor) (see chapter 3.1).
- Use of foreign protective strip. Must always be non-magnetic.
- Sensor not or incorrectly connected (pin connection, see chapter 4.1).
- Tolerance for the gap between magnetic sensor and magnetic strip not observed over the **total** travel distance (see fig. 6).
- Cables squeezed / interrupted / cut by sharp edges.
- Sensor's active side not mounted towards the magnetic strip (see fig. 6).
- Sensor has not been aligned according to fig. 6.



**SIKO GmbH**

**Werk / Factory:**

Weihermattenweg 2  
79256 Buchenbach-Unteribental

**Postanschrift / Postal address:**

Postfach 1106  
79195 Kirchzarten

**Telefon/Phone** +49 7661 394-0

**Telefax/Fax** +49 7661 394-388

**E-Mail** info@siko.de

**Internet** www.siko-global.com

**Service** support@siko.de